

Moxa PCI

-DOS

For MOXA

2006-8-17

MOXA C168/PCI CP168 C104/PCI CP104 CP102 CP104
 CP118 CP132 CP134 CP168
 DOS 6.22

```

1          PCI
2          A ( )
3          DOS 6.22 FAT32
4 C:\>a:          ** A ( )
5 A:\>dosinst    **
6          ( C:\moxa)
7 " F2"
8          " Y"
9
    
```

1 2 3 4

MOXA

```

10 " F10"
11 C:\MOXA\BIN>dp-drv ** API-232
12 C:\MOXA\BIN>cd\    ** C
13 C:\>edit autoexec.bat ** autoexec.bat
14 edit              " c:\moxa\bin\dp-drv.exe" (API-232 )
                  " c:\moxa"
    
```

```

1 C:\>moxa\bin\scope ** scope.exe MOXA DOS
2          " F4"          " F5"          Loop back
3 " +"          " F6"          OK
4          Port 1 Port 2 ( )
5          " F4"          " F6"          " TXD-x-RXD
RXD-x-TXD          TXD——RXD RXD——TXD
    
```

